### 10 YEAR MANUFACTURER'S

#### LIMITED WARRANTY

All parts of this Kingston Brass faucet are warranted to the original retail purchaser to be free from defects in material and workmanship for a period of Ten(10) years from the date of purchase as shown on the purchaser's receipt.

This warranty is limited to defective parts only, labor charges and/or damage resulting from improper installation, repair or replacements, as well as incidental and consequential damages connected therewith are excluded.

Any damage to this faucet as a result of misuse, abuse, neglect, accident, or improper installation or any use not consistent with the instructions furnished by us, will void this warranty.

Replacement parts can be obtained from your local dealer. Freight cost is not covered by manufacturer.


## CAUTION!!!

- 1. Water lines must be completely flushed before use, to avoid debris & clogs in your water system leading to mal-function and reduction of water flow.
- 2. Warranty to be void if water lines are not flushed before use of new faucet.
- 3. Use of abrasives of any strength may damage the finish of your faucet and void this warranty.

| PROBLEMS SHOOTING               |                                |  |  |
|---------------------------------|--------------------------------|--|--|
| PROBLEM                         | CAUSE                          | CORRECTIVE ACTION  |  |
| Leaks underneath handle         | Bonnet nut has come loose      | Remove the handle and tightening the bonnet nut                                |  |
| Leaks from the spout            | Valve seat and spring are worn | Replace the valve seat and spring  |  |
| Inconsistent water flow pattern | Aerator is dirty or aged       | Release aerator and check on rubber gasket if aged or replace with new aerator |  |
| Faucet is dirty                 | Caused by stubborn water spot  | Clean with mild soap and warm water as often as possible                       |  |
| Handles works backward          | Handle install backward        | Rotate the right stem stop assembly 180 degrees                                |  |

CODE APPROVAL: LA#M-000018





# Parts:

| &        | Cone Washer  | Pop-Up |
|----------|--------------|--------|
| LOCK NUL | Coupling Nut |        |
|          |              |        |
| X1       | X2           | X1     |

www.kingstonbrass.com


TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS TECHNICAL SUPPORT E-mail: service@kingstonbrass.com 12775 Reservoir Street, Chino, CA91710




# INSTALLATION INSTRUCTIONS For Use With KB's Widespread Lavatory Faucets with Pop-Up

#### BEFORE BEGINNING INSTALLATION


- 1. Flush plumbing lines to clear debris in pipe and plumbing lines to avoid existing clogs into waterway & cartridge system of new faucet fixture.
- 2. Shut off both supply lines after flushing




1.Shut off hot and cold water supply under sink. Plug sink drain with cloth to avoid losing small parts. Remove old faucet.




3. Hold the handles in proper position. Make sure that the top of the faucet handles is 5/8" above the top of the sink. Mount the metal washer and locknut from underneath the sink. Than reposition escutcheons as necessary to a desired height.




5. Turn on water supply valves and check for leaks, especially at hook-ups to supply lines.




Install new faucet spout through the center hole of sink. Place mounting washer on spout shank and attach with spout shank locknut.




4. Connect the water supply lines. Before connecting the supply lines, apply pipe joint compound to the threads on the inlet shanks and shut off valves with an adjustable wrench.




Thread mounting nut and bottom gasket onto drain body. Wrap top threaded end of the drain body with plumbers' tape.







7. Install drain body up through the drain opening and reattach the flange onto drain body, holding the drain body in position with pivot rod opening facing the back of sink. Tighten the mounting nut by hand.




8. Place pivot rod into pivot rod opening. Slide pivot nut over pivot rod and thread it on the drain body. Tighten firmly.



9. With lift rod in position on the faucet, insert lift rod through lift rod strap and secure with the clevis screw.



10. Guide the pivot rod through one of the holes on the lift rod strap and secure it with the spring clip. Then adjust the height of the lift rod by resetting the clevis screw.



11. Remove the aerator before turning on your new faucet for the first time. This is to prevent any deposits from clogging your aerator. Allow both hot and cold water to run for one minute. Replace aerator.