



WALL MOUNT INSTALLATION INSTRUCTIONS

Cuzco Wall Mount Vanity

1. Check the specified height or determine desired height and determine where studs are located in the wall. (If no studs can be found, use heavy duty wall mounting hardware to secure vanity to the wall.) Wall mounting hardware can be found at any major hardware store.
2. Mark cross beam on back of vanity where studs line up with the vanity back.
3. Drill holes for lag bolts that line up with wall studs and height in the metal cross beam on the back of the vanity.
4. Drill pilot holes in walls and through studs so that studs will not crack when lag bolt is tightened.
5. Support vanity against the wall and screw lag bolts through the vanity cross beam and into the wall.
6. Install top, sink, and drain according to installation instructions.

Bordeaux Wall Mount, Halcyon Vanity and Harmony Vanity

1. Check the specified height or determine desired height and determine where studs are located in the wall. (If no studs can be found, use heavy duty wall mounting hardware to secure vanity to the wall.) Wall mounting hardware can be found at any major hardware store.
2. Drill holes for lag bolts that line up with wall studs and height of vanity in the wooden French cleat provided. Make sure slanted edge will fit correctly into the vanity.
3. Drill pilot holes in walls and through studs so that studs will not crack when lag bolt is tightened.
4. Screw lag bolts through wooden French cleat and into the wall making sure it is level and at the right height to support the vanity.
5. Hang vanity on the French cleat attached to the wall.
6. Install top, sink, and drain according to installation instructions.