



designer bathrooms

WETSTYLE NC14 shampoo holder installation guide

1. Cut out an opening (13 ½ x 13 ½ inches) for holder NC14 in the wall where the holder is to be installed.
2. Spread silicone sealant along the edge of the holder where it will touch the wall, and insert it into the opening.
3. a) If possible, install the final cladding (ceramic) after installation of the holder. The grout will prevent water penetration.

b) For a pre-finished wall, apply joint sealant to the silicone around the holder. It is preferable to apply a masking tape onto the niche and the wall to apply the sealant and remove it promptly.