



For construction with wall studs on 16 in. centers, the header is located between the studs for the right side mounting. For construction with wall studs on centers greater than 19-1/2 in. provide secure header as shown.





Jeeves Model H Curved

Tel: 404-350-9738 www.ambaproducts.com Wire cover tube fits into centre of cover plate which fits over single gang box